

Care & Maintenance

Stream Coffee Table



Oak veneer, Oak wood

Daily Care & Maintenance

Dust with a dry cloth.

For more thorough cleaning & stain removal

Use a soft cloth wrung out in a mild detergent and finish with a dry cloth.

Make sure to remove stains immediately to avoid permanent damage.

Please note

Do not place the product to close to a heat surface, as this will dry out the wood and risk cracks on the surface.

Make sure, you move objects placed on the product regularly, to avoid marks and sun damage.

Hübsch

DANISH HOME INTERIOR & DESIGN